

Black Acrylic Countertop Entry Box

Installation Information

Product #: FATP06184

Assembly Instructions

1) Check all parts

- Entry Box
- Locking back sign channel
- Add-on front sign channel
- (2) Add-on brochure pockets

2) Insert locking back sign channel

With lock in open position, slide channel down through slot in back of the entry box.

3) Install add-ons

Add-on pockets and graphic channel can be installed on the front or sides.

- Peel the protective cover off the adhesive strip on the 8½" x 11" sign channel and push into place.
- The 4" brochure pockets have adhesive foam tape strips enclosed, peel and apply to back of holders then apply to desired area.

CAUTION: These adhesive strips are intended for permanent application.

