

Deluxe Acrylic Slant-Back Floor Display

Installation Information

Product #: FFFM00223

This is the **Main Body Unit** to your new **Acrylic Floor Display**. This unit is shipped in two separate containers. One box contains the main body of the unit with the four pocket literature holder attached, while the second box contains the base and mounting hardware. Both boxes should arrive together. If not, they were probably separated in transit and should arrive tomorrow or the next day. If they do not arrive, please call **M.F. Blouin** at **1(800)-394-1632** and we will trace shipment with the carrier.

Assembly Instructions

- 1) To avoid scratching, carefully unpack the pieces on a carpeted floor, or throw-cloth, and proceed to assemble the unit on it's side.
- 2) Observe that for balance & stability, the **Base Plate** must be oriented so that the longer end (or tail) faces backward (see illustration).
- 3) Locate the three hex screws in a plastic bag taped to the **Base Plate**. Insert the three hex screws through the base into the main body of the unit and tighten with the hex key provided (see illustration).

